

Display

Antenna switching diversity

Mute lock

Mute

Frequency

App connection

Key lock

Menu

Radio frequency level

Transmitter audio level

Gain

Audio output level

Channel

Transmitter battery

?

→

Instruction Manual

Menu

Gain

AF Out

Mute Lock

Auto Scan

Channel

Tune

Reset

?

→

Instruction Manual

www.sennheiser.com/download

Instruction manual

Bedienungsanleitung

Notice d'emploi

Istruzioni per l'uso

Instrucciones de manejo

Manual de instruções

Gebruiksaanwijzing

Instrukcja obsługi

Bruksanvisning

Betjenings vejledning

Käyttöohje

Οδηγίες λειτουργίας

Kullanım kılavuzu

Инструкция по эксплуатации

使用说明书

取扱説明書

사용 설명서

Smart Assist

Available on the App Store

ANDROID APP ON Google play

LEDs

LINK LED

DATA LED

EM

SKM-S

SK

LINK ok

audio active

Link ok

audio muted or no capsule on SKM

Link ok

audio clip

No link

Link ok

Low transmitter battery

No link

Device switched off

Bluetooth active to

sync with transmitter

connect with app

Firmware update in progress

DATA

LINK

?

→

Instruction Manual

Sync

EM

SKM-S

SK

short press

short press

short press

?

→

Instruction Manual

Key lock

press both

unlocked

locked

?

→

Instruction Manual

Mute

SK

SKM-S

Mute Lock

→

Instruction Manual

Color coding sets

optional accessories for EM, SK and SKM-S

wireless link 1

wireless link 2

etc.

etc.

?

→

Instruction Manual

SKM-S

correct use

incorrect use

ME 2


ME 3


ME 4

25 cm (10")

2...3 cm (1")

Antennas





\*optional accessories:  
ADP UHF (470 - 1075 MHz)  
AD 1800 (1400 - 2400 MHz)



[www.sennheiser.com/download](http://www.sennheiser.com/download)


Smart Assist

Download on the App Store

GET IT ON Google Play

Sennheiser electronic SE & Co. KG  
Am Labor 1, 30900 Wedemark, Germany  
[www.sennheiser.com](http://www.sennheiser.com)

Printed in Germany  
Publ. 10/24, 583962/A06



Evolution Wireless Digital

EW-D EM  
EW-D SK  
EW-D SKM-S

Quick Guide  
Kurzanleitung  
Guide rapide  
Guida rapida  
Guía de inicio rápido  
Guia rápido  
Beknopte handleiding  
Krótka instrukcja obsługi  
Snabbguide

Kort vejledning  
Pikaohje  
Γρήγορος οδηγός  
Kisa Kilavuz  
Краткая инструкция  
快速指南  
クイックガイド  
퀵 가이드

Audio Out



XLR-3 6.3 mm

OR

Power supply



EU US UK AU KOR CN


Smart Assist

The **Smart Assist** app simplifies your workflow

- Smart Assist app provides automated setup, operation and monitoring using any iOS or Android device
- Intelligent setup automatically creates reliable wireless connections, no wireless expertise required
- Mobile access to all system settings centralizes control and eliminates the need for complicated menu navigation on each device
- Easy frequency allocation and wireless channel naming help to keep systems organized

Download on the App Store

GET IT ON Google Play



In the box



Rack mount angles  
Power supply adapters  
Power supply

Battery



2 AA batteries (included) \*optional: BA 70 rechargeable battery

SKM-S



2 AA batteries (included) \*optional: BA 70 rechargeable battery

EW-D EM





On/Off





Off -> On	 <b>EM/SK/SKM-S</b> short on
On -> Off	 <b>EM/SK/SKM-S</b> long off

Identify/Battery check



On -> Identify/Check	 <b>SK/SKM-S</b> short Identify/Check
----------------------	---

LINK LED SK/SKM-S	
	≤ 100 %
	≤ 60 %
	≤ 20 %

Display of synced EM

EW-D SKM-S



EW-D SK

