



SL PASC 4

Quick Guide
Kurzanleitung
Guide de démarrage rapide
Guida rapida
Instrucciones resumidas
Instruções resumidas
Beknopte gebruiksaanwijzing
Krótka instrukcja obsługi
Snabbguide

Kort vejledning
Pikaohje
Γρήγορος οδηγός
Kısa Kılavuz
Краткая инструкция
快速指南
快速使用指南
クイックガイド
퀵 가이드

SENNHEISER



www.sennheiser.com/download

Sennheiser electronic SE & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Publ. 09/24, 583929/A03


SL PASC 4



8 x R-SMA



Operating elements




Specifications

Frequency range	1,880 - 1,930 MHz
Insertion loss	-8 dB typ.
Port to port isolation	26 dB min.
Input / Output return loss	-14 dB max
Connectors	AC coupled ports
Max. input power	1.5 W max
Dimensions	210 x 160 x 41 mm
Weight	663 g
Operating temperature	-40 to 85 °C
Relative humidity	max. 95 % (non-condensing)

Accessories


Remote antennas and
maximum cable lengths




Instruction Manual
SpeechLine Digital Wireless

www.sennheiser.com/download

A: 4x SL Rack Receiver DW + AWM 2



B: 8x SL Rack Receiver DW + AWM 4



Instruction manual | Bedienungsanleitung | Notice d'emploi | Istruzioni per l'uso | Instrucciones de manejo | Manual de instruções |
Gebruiksaanwijzing | Instrukcja obsługi | Bruksanvisning | Betjeningsvejledning | Käyttöohje | Οδηγίες λειτουργίας |
Kullanım kılavuzu | Инструкция по эксплуатации | 使用说明书 | 使用説明書 | 取扱説明書 | 사용 설명서